

PSCD-01

USB programmer for dCSS multiswitches and Smart Splitter



Management via LEM GUI software



LED Status / Operation



Supplied with power supply



Programmer to change and personalize the set up of the User Band frequency slots in dynamic or static mode. It can be programmed to send SCR-dCSS-SKY UK DSCR messages to check the dCSS/SCR Multiswitch outputs. The programmer is managed using the LEM GUI software available for Windows PC.





MODEL		PSCD-01
FREQUENCY RANGE	MHz	5 2200
INSERTION LOSS	dB	1
PC INTERFACE		USB
DIMENSIONS	mm	102x48x27



