


SCF316/6

Optical Input Multiswitch User manual

- 6 Legacy/dCSS DTT/DAB/FM outputs
- Led monitor optical link
- A.C.G. for each output
- Selectable Low/High satellite output level
- Level adjuster for TV terrestrial signal



Ready for **MADE IN ITALY**

MODEL		SCF316/6
OPTICAL INPUT		1
RF OUTPUTS		6
OPTICAL		
OPERATION WAVELENGTH	nm	1310 - 1330 - 1550
INPUT POWER RANGE	dBm	-14 0
INPUT CONNECTOR TYPE		SC/APC
RETURN LOSS	dB	≥40
SATELLITE		
OUTPUT BANDWIDTH	MHz	950 2150
SCR/dCSS OUTPUT LEVEL	dΒμV	85 Low / 94 High
LEGACY OUTPUT LEVEL	dΒμV	75 Low / 80 High
SATELLITE OUTPUTS CONTROL STANDARDS		LEGACY/EN50494/EN50607/SKY UK (AUTO-SWITCH)
AVAILABLE USER BAND FREQUENCY PLANS		SKY ITALIA - SKY UK
TV TERRESTRIAL / FM / DAB		
OUTPUT BANDWIDTH	MHz	40 790
MAXIMUM OUTPUT LEVEL	dΒμV	85
OUTPUT LEVEL ADJUSTABLE RANGE	dB	020
OTHERS		
ISOLATION BETWEEN SATELLITE/TERRESTRIAL	dB	≥ 40
ISOLATION V / H	dB	> 30
OUTPUT RETURN LOSS	dB	> 10
DC INPUT VOLTAGE RANGE	V	12 20
MAXIMUM CONSUMPTION	W	13
OPERATING TEMPERATURE	°C	0 50
DIMENSIONS	mm	202x118x38

DESCRIPTION OF SYMBOLS AND ELECTRICAL SAFETY				
CE	The equipment complies with the CE requirements			
	The equipment is designed for indoor use only			
	Equipment grounding terminal			
	This symbol indicates that the equipment complies with the class II equipment safety requirements			
CAUTION	To avoid the risk of electric shock, do not open the equipment.			
RoHS 2002 95 EC	The equipment is compliant with RoHS 2011/65EU			
	Dispose according to local authorities recycling processes			

Safety instructions

- 1. Read carefully these instructions
- 2. Keep these instructions
- 3. Heed all warnings
- 4. Follow all instructions
- 5. Do not expose this apparatus to extreme temperatures
- 6. Do not install this apparatus near water or expose to rain and moisture
- 7. Place the apparatus in a dry and well-aired location
- 8. Install the unit on a vertical wall, or in a waterproof cabinet with a minimum IP55 rating, and fix it safely using the provided fixing plugs
- 9. Do not install the unit lying flat or on its top
- 10. Connect the power adapter cord to a detachable power supply socket
- 11. Unplug the apparatus during lighting storms or when unused for long time
- 12. Only use accessories specified by the manufacturer
- 13. Do not remove the cover without disconnecting from the mains first
- 14. Ambient temperature should not be lower than 0°C and higher than 50°C
- 15. Please allow air circulation around the apparatus



Installation warnings


Place the apparatus and the power supplier in a dry and well-aired location

Install the unit on a vertical wall, or in a waterproof cabinet with a minimum IP55 rating, and fix it safely using the provided fixing plugs

Use only the power supplier YS25-1501250 provided with the amplifier.

The use of not-original power suppliers determines the not-compliance of the product and can cause malfunctions and void the warranty


Minimum recommended distance



SCF316/6 DESCRIPTION

Box Content

- 01 Optical Multiswitch SCF316/6
- 01 Power supplier YS25-1501250 (Input: 100-240Vac 0,5A Max / Output: 15Vdc 1,25A Max)
- 08 6x30mm fixing plugs with 4,5x40mm screws
- 01 User manual
 - 1 Optical SC/APC input
 - (2) Terrestrial signals output level adjuster
 - (3) SCR/dCSS Legacy output Led status
 - (4) Terrestrial/SCR/dCSS Legacy Outputs
 - (5) Satellite High/Low level outputs (5) e (6) selector
 - (6) DC input 12... 20 Volt
 - (7) Satellite High/Low level outputs (3) e (4) selector
 - 8 Satellite High/Low level outputs (1) e (2) selector
 - (9) Equipotential bonding
 - (10) Optical link Status Led



The optical signal level at the input of the multiswitch **SCF316/6** must lie between 0dBm e -14dBm.



Optical signals higher than 0dBm can irreversibly damage the **SCF316/6** multiswitch. In PON with less than 4 optical points add a proper optical attenuator.

MONITOR LED DESCRIPTION

DC Input

Off= No power

Green= Power

Optical Link

Off= No optical link

Green= Optical link

Outputs

Multiswitch mode selected

Off= any voltage from set-top-box


Green blinking= Voltage from set-top-box < di 9 Volt

Green= Legacy mode (auto-switch)

Blue= SCR/dCSS mode (auto-switch)

Quattro mode selected

Green for all outputs



The **TXWBT** headend converts and transmits over a single-mode optical fibre the terrestrial signals (DTT, FM, DAB) processed by the programmable terrestrial headend **DSP20** and all the transponders of a satellite received from a Wide Band LNB. The optical signals are received by the optical multiswitch of the **SCF316** series and converted into RF ready for a single or multi-dwelling coaxial distribution. Each **SCF316** series output provides terrestrial and satellite signals supporting the legacy or SCR/dCSS standards (AUTO-SWITCH).

USER BAND FREQUENCY PLAN			
EN 50494 (SCR Standard)	EN 50607 (SCD2 / dCSS)		
UB1: 1210 MHz	UB1: 1210 MHz		
UB2: 1420 MHz	UB2: 1420 MHz		
UB3: 1680 MHz	UB3: 1680 MHz		
UB4: 2040 MHz	UB4: 2040 MHz		
UB5: 985 MHz	UB5: 985 MHz		
UB6: 1050 MHz	UB6: 1050 MHz		
UB7: 1115 MHz	UB7: 1115 MHz		
UB8: 1275 MHz	UB8: 1275 MHz		
	UB9: 1340 MHz		
	UB10: 1485 MHz		
	UB11: 1550 MHz		
	UB12: 1615 MHz		
	UB13: 1745 MHz		
	UB14: 1810 MHz		
	UB15: 1875 MHz		
	UB16: 1940 MHz		

